



Toyota and Scion Maintenance Service Benefits

For vehicles with a 16,000 km oil change schedule

ECP Benefits:

To maintain the quality of the investment you made in your new Toyota/Scion, regular maintenance is required every 6 months or 8,000 km, whichever comes first.

GOLD PLAN

Includes **4** Maintenance Benefits*

Expires at **36 months / 60,000 km †**

PLATINUM PLAN

Includes **6** Maintenance Benefits*

Expires at **48 months / 80,000 km †**

*The benefits are provided for plans that are purchased within 31 days of the warranty registration date.

Benefits Covered by ECP:

Service Interval †	GOLD	PLATINUM
6 months or 8,000 km	Service 1 and CBES‡	Service 1 and CBES‡
12 months or 16,000 km	Service 1 and 2	Service 1 and 2
18 months or 24,000 km	Service 1	Service 1
24 months or 32,000 km	Service 1, 2 and 3	Service 1, 2 and 3
30 months or 40,000 km	-	Service 1
36 months or 48,000 km	-	Service 1, 2, and replace brake fluid

† Whichever comes first, time or mileage

‡ Customize vehicle features in accordance with customer preferences

SPECIAL OPERATING CONDITIONS

If you primarily operate your vehicle under any of the following conditions, please refer to *additional maintenance requirements*, shown below:

- Driving on dirt roads or dusty roads
- Extensive idling and/or low-speed driving for long distances, such as police, taxi or door-to-door delivery service
- Towing a trailer, using a camper or car top carrier

ADDITIONAL MAINTENANCE REQUIREMENTS

- Inspect brakes, steering and suspension components every 6 months/8,000km
- Inspect driveshaft boots and body/chassis bolts, every 6 months/8,000km
- Change manual transmission oil every 36 months/48,000 km
- Replace automatic transmission fluid every 72 months/96,000 km

Maintenance Services:

SERVICE #1

- Inspect & adjust all fluid levels
- Reset maintenance reminder light (if applicable)
- Remove & inspect cabin air filter (replace if needed ¶)
- Remove & inspect engine air filter (replace if needed ¶)
- Inspect wiper blades, linkage & washers for proper operation
- Check installation of driver's floor mat
- Check & adjust tire pressures (including spare)
- Remove wheels & visually inspect brake pads, calipers, rotors, brake lines & hoses ¶
- Check & record tire tread depth
- Examine tires for damage & uneven wear
- Rotate tires (applicable to same size wheels, front & rear) or alternatively perform season tire change-over (tires mounted on rims); extra charges will apply if seasonal tires are not mounted on rims
- Record inspection results, measurements & component conditions on inspection form &/or repair order
- Road-test vehicle

SERVICE #2

- Replace engine oil & oil filter (0W20 or 0W30 as required)
- Lubricate locks, latches & hinges
- Inspect lights, horn & wipers for proper function
- Check coolant, brake, transmission & washer fluid levels (fill as required)
- Visually inspect drive belts (adjust tension if required)
- Tighten & lubricate propeller/drive shaft (if applicable)
- Inspect differential & transfer case vents for obstruction (if applicable)

SERVICE #3

- 12 Volt battery service & comprehensive electrical charging system evaluation
- Inspect valve clearance audibly
- Adjust belt tension (if required)
- Check steering gear linkage & shock absorbers for looseness, damage or leakage
- Inspect ball joints & dust covers, driveshafts, chassis nuts & bolts for looseness or damage
- Inspect fuel system for leaks or damage, inspect condition of fuel tank band, fuel tank cap gasket, fuel tank vapour vent system hoses, fuel lines & connections
- Inspect exhaust system for leaks, damage or broken hangers

¶ The maintenance benefits do not include any items that require periodic replacement, such as engine air filters, cabin air filters, wiper blades, belts, hoses, or brake pads.

The 36 MTH/48K maintenance service includes brake fluid replacement which is required as indicated in the Toyota/Scion Owner's Manual Supplement.